

GRIZZLY BARS
BACK DOOR REINFORCING KITS
INSTALLATION INSTRUCTIONS - COMMERCIAL

INSWING DOORS: (SINGLE & DOUBLE - IN OPENING)

COMPONENTS LIST:

- 2 - Mounting brackets
- 4 - 5/16" x 2" lag bolts
- 1 - 40° - 2 x 2 angle (80° for double doors)
- 4 - Spacers for angled doors
- 1 - Drawing (Fig. 6-B-2)

Position angle at desired height and mark location on door frame (be sure both sides are level).

Place mounting bracket at mark on door frame and locate hole positions for mounting. Drill pilot holes and bolt down firmly.

Lag bolts supplied are designed for installation on steel frames. Other mounting bolts may be needed to mount to other types of frames. (Steel frames are most common in commercial buildings). Make sure the mounting bolts hold with sufficient strength.

When brackets are installed drop angle into top of mounting brackets to complete installation.

